



SHOWCASE[®]
CUSTOM VINYL WINDOWS AND DOORS
Showcase 200 Series Horizontal Slider
INSTALLATION INSTRUCTIONS

General: The window assembly shall be installed in accordance with the manufacturer's installation instructions. Detailed installation instructions and drawings are available from the manufacturer.

Installation: The wood wall framing members shall be minimum Southern Yellow Pine lumber. The window shall be secured to the wall framing using the nailing fin of the window with minimum No. 10 screws. The fasteners shall be located approximately 4 inches from each corner and approximately 9 inches on center along the perimeter of the window. The fasteners shall be long enough to penetrate 1 ½ inches into the wall framing.