



SHOWCASE[®]
CUSTOM VINYL WINDOWS AND DOORS
200 Series IMPACT Picture Window
INSTALLATION INSTRUCTIONS

General: The window assembly shall be installed in accordance with the manufacturer's installation instructions. Detailed installation instructions and drawings are available from the manufacturer.

Installation: The wall framing shall be minimum Spruce-Pine-Fir dimension lumber. The window shall be secured to the wall framing using the nailing fin of the window with minimum 8d ring shank nails. The fasteners shall be placed at the corners and in every other pre-punched hole in the nailing fin. In addition, a minimum 1x2 wood furring strip shall be placed over the nailing fin along the perimeter of the window. The wood furring strip is secured in place with minimum No. 10 wood screws spaced approximately 3 inches from each corner and approximately 18 inches on center. The fasteners shall penetrate through the nailing fin and into the wall framing. All fasteners shall be long enough to penetrate a minimum of 1 ½" into the wall framing.