

## 300 Series Standard Mull

**Step One:** Cut the nail fins off the top of the bottom window and the bottom of the top window.

**Step Two:** Line the windows up and cut the accessory groove at the corners, starting on the inside of the window.



**Step Three:** Insert the mull cover into the accessory groove on each window.



**Step Four:** Flip the window over and cut the accessory groove at the corners.

**Step Five:** Apply silicone to the inside edges of both windows.



**Step Six:** Insert the mull cover into the accessory groove.



**Step Seven:** Fill the gap between the windows with silicone and smooth it out to ensure there are no gaps. Do this on both sides of the window.



**Step Eight:** Attach the metal strap over the silicone using 4-5 screws. This needs to be done to both sides of the window.

